



Estimated TimeTablet data usage

Last updated - Jun 02, 2020 at 2:55PM

Web:	https://timedock.com
Email:	info@timedock.com
International:	(+64) 9 444 1384
Local phone:	(09) 444 1384


The following table is a rough estimate of TimeTablet data usage. Actual usage may vary from time to time and also depend on other external and internal factors.

Employees	Estimated data usage (per device)
5	70mb per month
10	75mb per month
25	90mb per month
100	165mb per month


Inserting a Sim Card

Follow these steps to insert a sim card into your TimeDock wall-mounted hardware:

1. On the right-hand side of the device, pull open the SD and Sim card slot cover.
2. Insert the sim card into the **bottom slot with the chip facing forward**. If your sim card is a different size to the card slot, use a sim card adapter to convert it to the correct size.



3. To check that the card has been inserted correctly, tap your master key card to your device and navigate to *System > Wireless & networks > SIM cards*.



Note: An *activated* sim card with a current data plan is required. Internet compatibility may depend on your region, carrier, and type of card.