



Un-pair a TimeTablet from an account

Last updated - Jul 18, 2025 at 3:10PM


Web:	https://timedock.com
Email:	info@timedock.com
International:	(+64) 9 444 1384
Local phone:	(09) 444 1384

Follow these steps to un-pair/disconnect a TimeTablet from an account:


1. Swipe your master key card to the device to access the admin menu.
2. Tap on the *System Settings* icon.




3. Scroll down and tap on *Device > Apps*.



4. Scroll to the bottom of the app list and tap on *TimeTablet*.



5. Tap on *Storage*.



6. Tap on *Clear Data*. A confirmation dialog will appear, tap *OK*.

